

KINETIC CLASSICGAITER BOOT FOOT (CLEATED SOLE)

Item No
H153

Waders Size Chart

Choosing the right size is the key for optimal comfort and performance. The right fit must be snug but not too tight. Too tight fit can cause stretching of the seams and result in leakage.

The sizes are available in Standard. An average built person's starting point is the Standard size.

To give you an indication of your size, follow the measurements shown in the tables below, using the 6 measuring points being Waist, Hip, Thigh, Inseam, Outseam and Sock inside length. This will give you a fairly good idea about the size you need, but trying the waders at your local retailer is always recommended.

KINETIC WADERS SIZE CHART

Standard	38-39	40-41	42-43	44-45	46-47	46-47
Chest cm	112	117	127	127	132	140
Hip cm	109	114	124	124	130	137
Thigh cm	72.5	75	80	80	83	86.5
Inseam cm	87	90	94	94	95	98
Outseam cm	141	145	152	152	154	159
Boot inside length cm	25,5	26,5	28,5	30	30,5	30,5

